



# HP Compaq C700 Keyboard Replacement

This guide details how to remove the keyboard of the HP Compaq C700.

Written By: Taylor Johansen



## INTRODUCTION

In this guide, you will learn how to remove the keyboard of the HP Compaq C700 laptop.

---



### TOOLS:

- [Metal Spudger](#) (1)
-


## Step 1 — Keyboard



⚠ It is advised to work on the device only when it is powered off so as to avoid electrocution risks.

- Turn off computer by pressing and holding the power button.

## Step 2



- Locate the metal hooks where the keyboard connects to the laptop and use a metal spudger to gently pry up the keyboard.



## Step 3



- Gently lift up and remove the keyboard.

To reassemble your device, follow these instructions in reverse order.

This document was last generated on 2017-06-26 03:14:13 PM.